









Art. 6000 / DN 50





6000.Montageanleitung

- Der Spülsensor ist **nicht im Lieferumfang** enthalten!!!
- The rinsing sensor is **not included** in the scope of **delivery**!!!
- Le capteur de rinçage **n'est pas inclus** dans **la livraison** !!!
- Il sensore di risciacquo **non è compreso nella fornitura**!!!
- De spoelsensor is **niet bij de levering inbegrepen**!!!
- Czujnik płukania **nie jest objęty** zakresem **dostawy**!!!
- Oplachovací senzor **není součástí** **dodávky**!!!
- Oplachovací senzor **nie je súčasťou** **dodávky**!!!
- Az öblítő szenzor **nem tartozik a szállítási** terjedelemez!!!
- El sensor de enjuague **no está incluido en el volumen de suministro**!!!